

PNWD-SA-9523

## Millimeter-wave Advanced Imaging Technology

2011 Joint AAPM/COMP Meeting – Vancouver, Canada



Doug McMakin  
David Sheen  
August 3, 2011


Pacific Northwest  
NATIONAL LABORATORY  
*Proudly Operated by Battelle Since 1965*

## Outline


- Introduction
- Background on Millimeter-wave Imaging of Humans
- Millimeter-wave Security Scanner
- Millimeter-wave Safety Standards
- Future Checkpoint Improvements
- Standoff Detection
- Health Applications
- Conclusions

Pacific Northwest  
NATIONAL LABORATORY


## Explosives Detection Applications



Security Checkpoints



Standoff detection of person-borne IEDs




Integrated tri-portal concept

mmWave whole-body imager  
Metal detector  
Shoe scanner

Pacific Northwest  
NATIONAL LABORATORY

## Millimeter-wave Imaging of Humans





Body Measurements    Security Screening    Passive MMW Security    Standoff Detection

RF	Microwave	Millimeter-Wave	Sub-mm / Terahertz
300 MHz	3 GHz	30 GHz	300 GHz
Frequency			

Pacific Northwest  
NATIONAL LABORATORY


## Worldwide Deployment mmW AIT



[http://www.tsa.gov/approach/tech/imaging\\_technology.shtm](http://www.tsa.gov/approach/tech/imaging_technology.shtm)

## Holographic Imaging

How It Works



Courtesy of L-3 Communications

## L-3 ProVision®

### Active Millimeter Wave Portal


- Walk-through – stop 2 seconds
- Detects metals, and non-metals
  - Metals, ceramics, wood, plastic, etc.
  - Liquids and gels
  - Paper and coin currency
- Safe radio waves
  - Max. Peak EIRP: -11.6 dBm
  - 10,000 times lower power than a phone
- Fast: 200 – 400 people per hour
- Operational Frequency: 24.25 – 30 GHz
- Two Vertical Antenna Arrays
  - 384 elements per array (2 x 192)
  - One for front, one for back



Pacific Northwest  
NATIONAL LABORATORY

## Image Resolution

- Image resolution is determined by the wavelength and the angular extent of the illumination
- The angular extent can be limited by the size of the aperture (aperture limited), or by the beamwidth of the antenna (antenna limited)



Pacific Northwest  
NATIONAL LABORATORY  
Proudly Operated by Battelle Since 1965

## Range Resolution

- Range resolution is determined by the bandwidth of the system

$$\delta_r = \frac{c}{2B}$$

- For example, a bandwidth of 10 GHz (e.g. 90-100 GHz operation) results in a range resolution of 1.5 cm



## Millimeter-wave Safety Standards

IEEE Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic Fields, 3 kHz to 300 GHz, IEEE Std C95.1™-2005, Table 9.

Frequency Range (GHz)	RMS power density (S) (W/m <sup>2</sup> )	Averaging time (min)
5 – 30	10	30 – 5
30 – 100	10	5 – 2.81
100 – 300	10 - 100	2.81 – 0.17

PNWD-SA-9523

## Equivalent Isotropically Radiated Power

- EIRP is the amount of power that a theoretical isotropic antenna would emit to produce the peak power density observed in the direction of the maximum antenna gain\*
- 11.6dBm<sup>†</sup> = ~0.00007 W emitted at the array output


Distance	Power Density mmW AIT (W/m <sup>2</sup> )	IEEE Standard (W/m <sup>2</sup> )
0.25 m	0.000089	10
0.50 m	0.000025	10
0.75 m	0.000011	10

\* [http://en.wikipedia.org/wiki/Equivalent\\_isotropically\\_radiated\\_power](http://en.wikipedia.org/wiki/Equivalent_isotropically_radiated_power)

† Telephone discussion with L-3 engineer – Scott Trospen

## Next-generation system

L-3 (TSA)



ProVision ATD (automatic target detection)


- Detects items on body
- Displays location on avatar

Addresses major TSA concern: *privacy issues!*

### Future Checkpoint



40 – 60 GHz  
V=Transmit  
V=Receive




40 – 60 GHz  
V=Transmit  
H= Receive


### Combined Cylindrical Algorithm



PNWD-SA-9523



### Future Walkthrough System




PNWD-SA-9523



### Standoff Detection

340 – 360 GHz @ 5 m



000004\_000\_000\_000\_000\_000

## Licensed Application

*Apparel, health & fitness markets*

• First of kind patented imaging technology  
 • 90 degree which back view & front view  
 • Detects 100% of 100kg & 100lb weapons load  
 • 100% accuracy for the apparel industry over 10000  
 • 100% weight gain or health care fitness monitoring  
 • A national of America, Canada, Europe and the UK 27 other states

**SPECIAL AVATAR MEASUREMENTS**  
 • Capabilities to scan from the front/back/side to 360 degree to monitor change of shape, monitoring or reduction of body fat, waist, hips, etc.

**ADVANTAGES**  
 Speed  
 Size  
 High throughput  
 Non-invasive  
 No contact  
 No radiation  
 No waiting  
 No privacy issues  
 No contact  
 No radiation  
 No waiting  
 No privacy issues  
 No contact  
 No radiation  
 No waiting  
 No privacy issues

**OPERATIONAL**  
 • High accuracy  
 • Capabilities to scan from the front/back/side to 360 degree to monitor change of shape, monitoring or reduction of body fat, waist, hips, etc.

**OPERATIONAL**  
 • High accuracy  
 • Capabilities to scan from the front/back/side to 360 degree to monitor change of shape, monitoring or reduction of body fat, waist, hips, etc.



## Conclusions

- Millimeter-wave technology is suitable for detecting person-borne threats concealed in clothing
- Commercial available millimeter-wave imaging technology is well below recognized health safety standards
- Next generation mmW AIT will improve detection and privacy
- Submillimeter-wave technology ideal for standoff weapons detection
- Security body scanner technology adapted to apparel, health, and fitness markets

Proudly Operated by Battelle Since 1965

## Acknowledgements

- The authors would like to thank the Transportation Security Laboratory in Atlantic City, New Jersey for funding the development of this technology. We would also like to thank our commercial partner, L-3 Communications, for their continued support and deployment of this technology

Proudly Operated by Battelle Since 1965

## Questions?

---



**Doug McMakin**  
Electromagnetics Team Lead  
Pacific Northwest National Laboratory  
[doug.mcmakin@pnl.gov](mailto:doug.mcmakin@pnl.gov)